


PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 2223 M

TWR	118.55, 118.7	RMP	122.80
PDC	122.1	D-ATIS	127.650
SMC	121.85, 121.0	FIS	126.875
		EMERG	121.5
HELICOPTEROS MEX		118.15	


MEXICO
AEROPUERTO INTL/
INTL AIRPORT
BENITO JUAREZ



CAMBIOS: ELEV AD

LAS MARCACIONES SON MAGNETICAS /
BEARINGS ARE MAGNETIC

ELEVACIONES Y DIMENSIONES EN METROS /
ELEVATIONS AND DIMENSIONS IN METERS



ZONA SIN VISIBILIDAD DESDE TWR, PRECAUCION AL TRANSITAR
ZONE OUT OF SIGHT FROM TWR, PROCEED CAUTIOUSLY

ESCALA / SCALE : 1 : 5500



PSN PLATAFORMA TANGO SUR 1		
PUNTOS	LATITUD	LONGITUD
P-82	19° 25' 29.2041" N	99° 05' 00.3696" W
P-83	19° 25' 30.2303" N	99° 05' 01.3417" W
P-84	19° 25' 30.8187" N	99° 05' 02.7889" W
P-85	19° 25' 31.4120" N	99° 05' 04.2345" W
P-86	19° 25' 31.9783" N	99° 05' 05.6844" W

PSN PLATAFORMA TANGO SUR 2		
PUNTOS	LATITUD	LONGITUD
P-87	19° 25' 28.37" N	99° 05' 10.01" W
P-88	19° 25' 26.94" N	99° 05' 10.95" W
P-89	19° 25' 28.70" N	99° 05' 14.01" W
P-90	19° 25' 30.05" N	99° 05' 13.25" W