


PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
 AIRCRAFT PARKING/DOCKING CHART

ELEV AD 2223 M


TWR	118.55, 118.7	RMP	122.80
PDC	122.1	D-ATIS	127.650
SMC	121.85, 121.0	FIS	126.875
		EMERG	121.5
HELICOPTEROS MEX		118.15	

MEXICO
 AEROPUERTO INTL/
 INTL AIRPORT
BENITO JUAREZ




LAS MARCACIONES SON MAGNETICAS /
 BEARINGS ARE MAGNETIC

ELEVACIONES Y DIMENSIONES EN METROS /
 ELEVATIONS AND DIMENSIONS IN METERS



ZONA SIN VISIBILIDAD DESDE TWR, PRECAUCION AL TRANSITAR
 ZONE OUT OF SIGHT FROM TWR, PROCEED CAUTIOUSLY

ESCALA / SCALE : 1 : 3600



CAMBIOS: ELEV AD

PSN PLATAFORMA REMOTA ORIENTE		
PUNTOS	LATITUD	LONGITUD
P-48	19° 25' 52.6125" N	99° 04' 01.4885" W
P-48-A	19° 25' 53.2914" N	99° 04' 02.0456" W
P-49	19° 25' 53.6108" N	99° 04' 02.4447" W
P-50	19° 25' 54.6103" N	99° 04' 03.4016" W
P-50-A	19° 25' 55.0314" N	99° 04' 03.7428" W
P-51	19° 25' 56.9296" N	99° 04' 02.8259" W
P-EA	19° 26' 02.5767" N	99° 03' 55.4033" W
P-EB	19° 26' 01.8365" N	99° 03' 56.6338" W

HELIPUERTO		
HRP	LATITUD	LONGITUD
	19° 25' 56.4998" N	99° 03' 53.7184" W